

Redi-Flo Variable Frequency Drive

USA Installation and operating instructions



SAFETY NOTICE

This equipment contains voltages that may be as great as 1000 volts! Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the start-up procedure or troubleshoot this equipment.

PRECAUTIONS:

-  **WARNING:** Do not touch any circuit board, power device or electrical connection before you first ensure that power has been disconnected and there is no high voltage present from this equipment or other equipment to which it is connected. Electrical shock can cause serious or fatal injury. Only qualified personnel should attempt the start-up procedure or troubleshoot this equipment.

-  **WARNING:** Be sure the system is properly grounded before applying power. Do not apply AC power before you ensure that grounds are connected. Electrical shock can cause serious or fatal injury.

-  **WARNING:** Do not remove cover for at least five (5) minutes after AC power is disconnected to allow capacitors to discharge. Electrical shock can cause serious or fatal injury.

-  **CAUTION:** Disconnect motor leads (T1, T2 and T3) from control before you perform a “Megger” test on the motor. Failure to disconnect motor from the control will result in extensive damage to the control. The control is tested at the factory for high voltage / leakage resistance as part of Underwriter Laboratory requirements.

-  **CAUTION:** Do not connect AC power to the Motor terminals T1, T2 and T3. Connecting AC power to these terminals may result in damage to the control.

QUICK START GUIDE

To operate the Redi-Flo VFD system, simply:

1. Submerge the RF2 or RF4 pump in the water to be pumped.
2. Connect the motor lead to the Redi-Flo VFD. (Note: With RF4 Variable Performance Pumps you must have an adapter cord to connect to Redi-Flo VFD.

#3 and #4 for operation with generator only.

WARNING: Do not let the generator run out of gas while powering the VFD. If it surges and creates excessive voltage, internal VFD damage could result.

3. If using a generator, start the generator and allow it to warm up.
4. If the generator has a circuit breaker, close the breaker and check the output voltage from the generator. The output voltage must be within the specified ranges (refer to Technical Specifications, at the end of this manual) to ensure proper operation and prevent damage to the system. If the voltage is too high or too low, adjustments to the generator must be performed to allow the system to run.
5. Plug the Redi-Flo VFD into a generator or connect to utility power supply. The unit accepts 115V or 230V sources. Refer to the Input Power Terminals section for wiring instructions.

WARNING: Incorrect wiring on the 115V or 230V terminals will damage the drive.

6. The VFD will initialize and be ready to drive the motor. After the initialization screen appears, the following will be displayed:

STP	OV	REDIFL2
LOC	0.0A	0.00HZ

- STP means the drive is stopped
- V indicates motor volts
- REDIFL2 indicates Redi-Flo2 pump mode
- LOC means the drive is in Local Keypad Mode
- A indicates motor amps
- HZ indicates motor frequency

The VFD defaults to Redi-Flo2 operation. To change to Redi-Flo4 press the sequence SHIFT-▼-SHIFT keys. Use sequence SHIFT-▲-SHIFT to return to Redi-Flo2.

7. Press the FWD key to start the motor and use the ▲ and ▼ arrow keys to increase or decrease speed. Continuous holding of the arrow key will increase the rate of speed change. The STOP key is used to stop the motor.
8. Pressing the ENTER key allows the user to quickly set the speed to any given value by using the ▲ and ▼ arrows to change speed and the SHIFT key to cursor between digits.
9. When powering down, unplug the Redi-Flo VFD from the generator BEFORE removing the motor lead from the Redi-Flo VFD or turning off the generator.

Note: To prevent tripping power source circuit breakers please observe the following: When using the Redi-Flo4 pump and a VFD power source of 115VAC, motor speeds of greater than 70Hz may draw over 15 amps. For 230VAC power source motor speeds greater than 90 Hz may draw over 15 amps. In RediFlo4 mode, 100 Hz cannot be exceeded without changing parameters.

PRE-INSTALLATION CHECKLIST

Components of Your Redi-Flo VFD System

Your Redi-Flo Variable Performance Pump system should contain the following components:

1. Redi-Flo Variable Frequency Drive, (See Figure 1)
2. Either a Redi-Flo2® pump and motor with lead (Figure 2) or a Redi-Flo4™ Variable Performance pump, motor, lead, lead/plug and RF4 x VFD adapter cord (Figure 3).




Figure 1



Redi-Flo2®




Figure 2



Figure 3

Redi-Flo4®

To operate the system you will also need:

1. A discharge hose or pipe to connect to the pump (See Figure 4).
2. An electrical plug to connect the Redi-Flo VFD power cord to your portable generator may be needed if the supplied plug is not compatible with your generator (See Figure 5).
3. Safety cable and hardware for lowering and lifting the pump (See Figure 6).

Figure 4



Figure 5



The exact type of plug used will depend upon your generator, The Redi-Flo VFD is supplied with a standard NEMA 5-15P, 115V, 3 prong plug.

Figure 6



Redi-Flo2®




Redi-Flo4®

ASSEMBLING THE REDI-FLO VFD SYSTEM

INPUT POWER TERMINALS

The input voltage can be changed between 115V and 230V by changing the line input connections as shown below:

Warning - If the Redi-Flo VFD is miswired for the incoming voltage, internal damage may occur to the drive.



Attaching the Pump to the pipe

When connecting the discharge pipe or tubing to the pump, a back-up wrench should be used. It is recommended that a safety cable be attached to the pump (using special brackets and cables, sold separately) anytime plastic pipe or flexible tubing is used (as shown in figure 6). A check valve may also be added to Redi-Flo2® pumps to prevent fluid from flowing back into the pump after it is turned off (backflow prevention). A check valve is standard on Redi-Flo4™ pumps. Always check to ensure joints are fastened securely. The use of a torque arrestor is not required when using the Redi-Flo VFD.

Lowering the Pump Into the Well

Make sure the electrical motor leads are not cut or damaged in any way when the pump is being lowered into the well. Do not use the motor leads to support the weight of the pump. To protect against surface water entering the well and contaminating the well, the well should be finished off utilizing a locally approved well seal.

The motor lead should be secured to the discharge pipe or tubing at frequent intervals to prevent sagging, looping and possible motor lead damage. Teflon® wire ties are recommended for environmental applications.

IMPORTANT

Plastic pipe and tubing tend to stretch under load. This stretching must be taken into account when securing the motor lead to the riser pipe or tubing. Leave three to four inches of slack between clipped points. This tendency to stretch will also affect the calculation of the pump setting depth. When plastic pipe or tubing is used, it is recommended that a safety cable be attached to the pump to raise and lower it. Redi-Flo4™ pumps are designed to accommodate this cable and Redi-Flo2® pumps can be fitted with a safety cable bracket (part number 1A0019).

ASSEMBLING THE REDI-FLO VFD SYSTEM

OPERATING CONDITIONS

To ensure the Redi-Flo Variable Performance Pumping system operates properly, follow these guidelines:

- The Redi-Flo2® or Redi-Flo4™ pump must be installed vertically with the discharge end pointed upwards.
- The electrical voltage supply to the Redi-Flo VFD must always be within + or - 10% of the specified power supply (103.5 - 126.5 VAC at 115V connection or 207 - 253 VAC at 230V).
- For best performance when operating on a generator, 115V generators should be set at 120V without load and 230V generators should be set at 240V without load. Use a separate meter to set voltage; do not rely on built-in meters found on generators. Verify generator voltage stays within tolerance at full load.
- The pump and motor must always be completely submerged in fluid to ensure lubrication and cooling of the motor.
- The temperature of the fluid being pumped should be according to the technical specifications shown in the motor specifications.
- The installation depth of the pump should always be at least three feet below the maximum drawdown level of the well.
- Redi-Flo pumps are not recommended for well development or pumping fluid containing abrasives.
- Redi-Flo2® pumps are not recommended for continuous operation applications.
- The warranty of the Redi-Flo pumps will be void if other than the Redi-Flo VFD is used or if corrosive fluids are pumped.
- The service life of dedicated Redi-Flo pumps may be compromised if the ambient water quality exceeds one or more of the following values:

pH<5 DO>2 ppm H2S>1 ppm CL->500 ppm TDS>1000 ppm

Adherence To Environmental Regulations

When handling and operating the Redi-Flo Variable Performance Pump system, all environmental regulations concerning the handling of hazardous materials must be observed. When the pump is taken out of operation, great care should be taken to ensure that the pump contains no hazardous materials that might cause injury to human health or to the environment.

Purging A Well

If the pump is used to purge a well, start the pump at minimum speed and gradually increase to desired speed. Redi-Flo products are not recommended for well development.

Generator Usage

Minimum generator size

For generators with voltage regulation
For generators without voltage regulation
Recommended for optimal performance

(Redi-Flo2/Redi-Flo4)

2500/3400 watts at 115/230VAC, single phase
5000/6700 watts at 115/230VAC, single phase
4000/5400 watts at 115/230 VAC, single phase
with voltage regulation

Dual Input Capability

Redi-Flo VFD can accept 115V or 230V single phase input voltage. Refer to the input power terminal section on page 4 for connection instructions.

Enclosure

The Redi-Flo VFD NEMA 4 enclosure is designed for outdoor duty and is resistant to damage as a result of incidental exposure to rain.

UL Approvals

The Redi-Flo VFD is UL Listed to U.S. and Canadian electrical safety standards.

Dual Functionality

The Redi-Flo VFD can change from operating Redi-Flo2® (MP1) to Redi-Flo4™ Variable Performance pumps with a few keystrokes.

Optimized Volts/Frequency (V/Hz) Pattern

The Redi-Flo VFD V/Hz pattern is specially optimized to allow the most efficient operation of Redi-Flo2® and Redi-Flo4™ variable performance pumps.

REDI-FLO VFD KEYPAD OVERVIEW

Overview

The keypad is used to program the control parameters, to operate the motor and to monitor the status and outputs of the control by accessing the display options, diagnostic menus and the fault log.



Indicator Lights

- JOG - (Green) lights when Jog is active.
- FWD - (Green) lights when FWD direction is commanded.
- REV - (Green) lights when REV direction is commanded.
- STOP - (Red) lights when motor STOP is commanded.

Motor Selection - The VFD defaults to Redi-Flo2 operation, to change to Redi-Flo 4, press the key sequence “Shift - ▼ - Shift.” Use the sequence “Shift - ▲ - Shift” to return to Redi-Flo2.


JOG - Press JOG to select the preprogrammed jog speed. After the jog key has been pressed, use the FWD or REV keys to run the motor in the direction that is needed. The JOG key is only active in the local mode.

FWD - Press FWD to initiate forward rotation of the motor. (Active in Local and Jog modes).

REV - Press REV to initiate reverse rotation of the motor. (Active in Local and Jog modes).

STOP - Press STOP to initiate a stop sequence. Depending on the setup of the control, the motor will either regen or coast to a stop. This key is operational in all modes of operation unless it has been disabled by the Keypad Stop parameter in the Keypad (programming) Setup Block.

LOCAL - Press LOCAL to change between the local (keypad) and remote operation.



DISP - Press DISP to return to display mode from programming mode. Provides operational status and advances to the next display menu item.

SHIFT - Press SHIFT in the program mode to control cursor movement. Pressing the SHIFT key once moves the blinking cursor one character position to the right. While in program mode, a parameter value may be reset to the factory preset value by pressing the SHIFT key until the arrow symbols at the far left of the keypad display are flashing, then press an arrow key. In the display mode the SHIFT key is used to adjust the keypad contrast.

RESET - Press RESET to clear all fault messages (in local mode). Can also be used to return to the top of the block programming menu without saving any parameter value changes.

Keypad Display - Displays status information during Local or Remote operation. It also displays information during parameter setup and fault or Diagnostic Information.

PROG - Press PROG to enter the program mode. While in the program mode the PROG key is used to edit a parameter setting.

▲ (UP Arrow).

Press ▲ to change the value of the parameter being displayed. Pressing ▲ increments the value to the next greater value. Also, when the fault log or parameter list is displayed, the ▲ key will scroll upward through the list. In the local mode pressing the ▲ key will increase motor speed to the next greater value.

ENTER - Press ENTER to save parameter value changes and move back to the previous level in the programming menu. In the display mode the ENTER key is used to directly set the local speed reference. It is also used to select other operations when prompted by the keypad display.

▼ (Down Arrow)

Press ▼ to change the value of the parameter being displayed. Pressing ▼ decrements the value to the next lesser value. Also, when the fault log or parameter list is displayed, the ▼ key will scroll downward through the list. In the local mode pressing the ▼ key will decrease motor speed to the next lesser value.

MOTOR CONTROL VIA KEYPAD

The Redi-Flo VFD can operate the motor in three (3) different ways from the keypad.

1. Speed adjustment using the Keypad arrow keys
2. Speed adjustment with Keypad entered values
3. JOG Command

1) Keypad arrow speed control

Press FWD or REV to select desired direction of motor rotation, then press or hold the up arrow key ▲ to increase speed or use the down arrow key ▼ to reduce motor speed. Continuously holding the arrow key will cause the speed to change in larger increments. The minimum speed increment produced by the arrow keys is defined in PROG/Keypad Setup/Keypad Speed INC. Default value of 0.10 Hz can be changed by the user.

2) Keypad speed entered value

Press the ENTER key and use the ▲ and ▼ arrow keys to adjust digits and the SHIFT key to cursor to the desired digit. Press ENTER when finished selecting desired motor speed to return to the display mode. Press the FWD or REV key to run the motor in the desired direction at the programmed speed.

3) JOG Command

The JOG key can be used to ramp the pump up to a predetermined speed in the forward or reverse direction. Press the JOG key then hold the FWD or REV key, and the pump will ramp to the speed set in PROG/Jog Settings/Jog Speed. Acceleration and deceleration times for Jog can also be set in this programming menu.

DISP Key




The DISP key can be used for accessing diagnostic and troubleshooting screens as shown below:

Action	Description	Display	Comments
Apply Power	Display mode showing mode, voltage, current & frequency status.	STP 0V REDIFL2 LOC 0.0 A 0.0 HZ	No faults present. Local keypad mode. If in remote mode, press local for this display.
Press DISP key	Scroll to fault log block.	PRESS ENTER FOR FAULT LOG	Press ENTER to view the fault log if desired.
Press DISP key	Scroll to diagnostic info block.	PRESS ENTER FOR DIAGNOSTIC INFO	Press ENTER to view diagnostic information if desired.
Press DISP key	Scroll to local speed ref. block.	PRESS ENTER FOR LOCAL SPEED REF	Press ENTER to change motor speed.
Press DISP key	Display mode showing output frequency.	STOP FREQUENCY LOCAL 0.00 HZ	
Press DISP key	Display mode showing motor speed (based on output frequency).	STOP MOTOR SPEED LOCAL 0 RPM	
Press DISP key	Display mode showing output current.	STOP CURRENT OUT LOCAL 0.00 A	
Press DISP key	Display mode showing output voltage.	STOP VOLTAGE OUT LOCAL 0 V	

MOTOR CONTROL VIA KEYPAD

Adjusting Display Contrast

When AC power is applied to the VFD, the keypad should display the status of the unit. If there is no display visible, or if it is difficult to read, use the following procedure to adjust the display. Contrast may be adjusted in the display mode when motor is stopped or running.

Action	Description	Display	Comments
Apply Power	No visible display		
Press DISP Key	Places control in display mode		Display mode.
Press SHIFT key 2 times	Allows display contrast adjustment		
Press ▲ or ▼ Key	Adjusts display intensity	<pre>ADJUST CONTRAST ⏏ (ENTER) TO SAVE</pre>	
Press ENTER	Saves level of contrast and exits to display mode	<pre>STP 0V 0 RPM LOC 0.0 A 0.0 HZ</pre>	

Advanced Programming

A password is required for advanced programming features. **Altering some default settings for Redi-Flo2 or Redi-Flo4 could possibly damage the motor or VFD.** For additional programming instructions, please refer to the full programming guide found at the Baldor website: www.Baldor.com The manual can be found under Support — installation and operation manuals. It is Baldor manual number MN715, Series 15H Inverter.

LEVEL 1 BLOCKS		LEVEL 2 BLOCKS	
Preset Speeds	Input	Output Limits	Brake Adjust
Preset Speed #1	Operating Mode	Operating Zone	Resistor Ohms
Preset Speed #2	Command Select	Min Output Frequency	Resistor Watts
Preset Speed #3	ANA CMD Inverse	Max Output Frequency	DC Brake Voltage
Preset Speed #4	ANA CMD Offset	PK Current Limit	DC Brake Frequency
Preset Speed #5	ANA CMD Gain	REGEN Limit	Brake on Stop
Preset Speed #6	CMD SEL Filter	REGEN Limit ADJ	Brake on Reverse
Preset Speed #7	Power Up Mode	PWM Frequency	Stop Brake Time
Preset Speed #8			Brake on Start
Preset Speed #9	Output	Custom Units	Start Brake Time
Preset Speed #10	Digital Out #1	MAX Decimal Places	
Preset Speed #11	Digital Out #2	Value at Speed	Process Control
Preset Speed #12	Digital Out #3	Value DEC Places	Process Feedback
Preset Speed #13	Digital Out #4	Value Speed REF	Process Inverse
Preset Speed #14	Zero SPD Set PT	Units of Measure	Setpoint Source
Preset Speed #15	At Speed Band	Units of MEAS 2	Setpoint Command
	Set Speed Point		Set PT ADJ Limit
Accel / Decel Rate	Analog Out #1	Protection	At Setpoint Band
Accel Time #1	Analog Out #2	External Trip	Process PROP Gain
Decel Time #1	Analog Scale #1	Local Enable INP	Process INT Gain
S-Curve #1	Analog Scale #2		Process DIFF Gain
Accel Time #2	Underload Set Point	Miscellaneous	Follow I:O Ratio
Decel Time #2		Restart Auto/Man	Follow I:O Out
S-Curve #2		Restart Fault/Hr	Encoder Lines
	V/HZ and Boost	Restart Delay	Integrator Clamp
Jog Settings	Ctrl Base Frequency	Factory Settings	Minimum Speed
Jog Speed	Torque Boost	Language Select	
Jog Accel Time	Dynamic Boost	STABIL ADJ Limit	Skip Frequency
Jog Decel Time	Slip Comp Adj	Stability Gain	Skip Frequency #1
Jog S-Curve	V/HZ Profile		Skip Band #1
	V/HZ 3-PT Volts	Security Control	Skip Frequency #2
	V/HZ 3-PT Frequency	Security State	Skip Band #2
	Max Output Volts	Access Timeout	Skip Frequency #3
		Access Code	Skip Band #3
Keypad Setup		Motor Data	Synchro Starts
Keypad Stop Key		Motor Voltage	Synchro Starts
Keypad Stop Mode		Motor Rated Amps	Sync Start Frequency
Keypad Run Fwd		Motor Rated Speed	Sync Scan V/F
Keypad Run Rev		Motor Rated Frequency	Sync Setup Time
Keypad Jog Fwd		Motor Mag Amps	Sync Scan Time
Keypad Jog Rev			Sync V/F Recover
3 Speed Ramp			Sync Direction
Switch on Fly			
LOC. Hot Start			Communications
			Protocol
			Baud Rate
			Drive Address

TROUBLESHOOTING GUIDE TO ERROR MESSAGES

INDICATION	POSSIBLE CAUSE	CORRECTIVE ACTION
Command Select	Incorrect operating mode programmed.	Change Operating Mode in the Level 1 Input block to one that does not require the expansion board.
	Need expansion board.	Install the correct expansion board for selected operating mode.
Bus Overvoltage Trip or HW Overvoltage	DECEL Rate set too low a value	Lengthen DECEL time. Add external dynamic braking resistors or module.
	Input voltage too high.	Verify proper AC line voltage. Use step down transformer if needed. Use line reactor to minimize spikes.
Bus Undervoltage	Input voltage too low.	Verify proper AC line voltage. Use step up transformer if needed. Check power line disturbances (sags caused by start up of other equipment). Monitor power line fluctuations with date and time imprint to isolate power problem.
External Trip	Motor draws excessive current.	Check motor for overloading. Verify proper sizing of control and motor.
	External trip parameter incorrect.	Verify connection of external trip circuit at J4-16. Set external trip parameter to "OFF" if no connection made at J4-16.
Hardware Protect	Fault duration too short to be identified.	Reset control. Check for proper grounding of power wiring and shielding of signal wiring. Replace control board.
Heatsink Temp	Motor Overloaded.	Correct motor loading. Verify proper sizing of control and motor.
	Ambient temperature too high.	Relocate control to cooler operating area. Add cooling fans or air conditioner to control cabinet.
	Built-in fans are ineffective or inoperative.	Verify fan operation. Remove debris from fan and heatsink surfaces. Replace fan or check fan wiring.

TROUBLE SHOOTING GUIDE (CONT.)

INDICATION	POSSIBLE CAUSE	CORRECTIVE ACTION
HW Desaturation	Accel/Decel rate set too short. Torque Boost set too high. Electrical noise in logic circuits. Motor overloaded.	Lengthen Accel/Decel rate. Reduce torque boost value. Check for proper grounding of power wiring and shielding of signal wiring. Verify proper sizing of control and motor or reduce motor load.
HW Power Supply	Power supply malfunctioned.	Check internal connections. Replace logic power board.
HW Ground Fault	Output current (motor current) leakage to ground.	Disconnect wiring between control and motor. Retry test. If GND FLT is cleared, reconnect motor leads and retry the test. Repair motor if internally shorted. Replace motor lead wire with low capacitance cable. If GND FLT remains, contact your dealer.
Motor Will Not Start	Motor overloaded.	Check for proper motor loading. Check couplings for binding. Verify proper sizing of control and motor.
	Motor may be commanded to run below minimum frequency setting.	Increase speed command or lower minimum frequency setting.
	Incorrect Command Select parameter.	Change Command Select parameter to match wiring at J4.
	Incorrect frequency command.	Verify control is receiving proper command signal at J4.
Motor Will Not Reach Maximum Speed	Max Frequency Limit set too low.	Adjust Max Frequency Limit parameter value.
	Motor overloaded.	Check for mechanical overload. If unloaded motor shaft does not rotate freely, check motor bearings.
	Improper speed command.	Verify control is receiving proper command signal at input terminals. Verify control is set to proper operating mode to receive your speed command.
Motor Will Not Stop Rotation	MIN Output Speed parameter set too high.	Adjust MIN Output Speed parameter value.
	Improper speed command.	Verify control is receiving proper command signal at input terminals. Verify control is set to receive your speed command.
Motor runs rough at low speed	Torque boost set too high.	Adjust torque boost parameter value.
	Misalignment of coupling.	Check motor/load coupling alignment.
	Faulty motor.	Replace with a new motor.

TROUBLE SHOOTING GUIDE (CONT.)

INDICATION	POSSIBLE CAUSE	CORRECTIVE ACTION
New Base ID	Replaced Control or circuit board.	Restore parameters to factory settings. Reset control.
No Display	Lack of input voltage.	Check input power for proper voltage.
	Loose connections.	Check input power termination. Verify connection of operator keypad.
	Adjust display contrast.	See Adjust Display Contrast.
NV Memory Fail	Memory fault occurred.	Press "RESET" key on keypad. Restore parameter values to factory settings. If fault remains, call dealer.
3 Sec Overload	Peak output current exceeded 3 sec rating.	Check PK Current Limit parameter in the Level 2 Output Limits block. Check motor for overloading. Increase ACCEL time. Reduce motor load. Verify proper sizing of control and motor.
1 Min Overload	Peak output current exceeded 1 minute rating.	Check PK Current Limit parameter in the Level 2 Output Limits block. Check motor for overloading. Increase ACCEL/DECEL times. Reduce motor load. Verify proper sizing of control and motor.
Over Speed	Motor exceeded 110% of MAX Output Freq parameter value.	Check Max Output Freq in the Level 2 Output Limits block.
Param Checksum	Memory fault occurred.	Press "RESET" key on keypad. Restore parameter values to factory settings. If fault remains, call dealer.
Unknown Fault Code	Microprocessor detected a fault that is not defined in the fault code table.	Press "RESET" key on keypad. Restore parameter values to factory settings. If fault remains, call dealer.
Unstable Speed	Oscillating load. Unstable input power. Slip compensation too high.	Correct motor load. Correct input power. Adjust slip compensation.
uP Reset	A software watchdog timer has reset the processor because a process has timed out.	Press "RESET" key on keypad. If fault remains, call dealer.
FLT Log MEM Fail	Corrupt data in fault log (may occur on older systems only).	Press "RESET" key on keypad. If fault remains, call dealer.
Current SENS FLT	Failure to sense phase current.	Press "RESET" key on keypad. If fault remains, call dealer.
Bus Current SENS	Failure to sense bus current.	Press "RESET" key on keypad. If fault remains, call dealer.

HOW TO ACCESS DIAGNOSTIC INFORMATION

Action	Description	Display	Comments
Apply Power	Display mode showing Local mode voltage, current & frequency status.	<pre> STP 0V REDIFLZ LOC 0.0 A 0.0 HZ </pre>	No faults present. Local keypad mode. If in remote/serial mode, press local for this display.
Press DISP key	Scroll to fault log block.	<pre> PRESS ENTER FOR FAULT LOG </pre>	Press ENTER to view the fault log if desired.
Press DISP key	Scroll to diagnostic info block.	<pre> PRESS ENTER FOR DIAGNOSTIC INFO </pre>	Press ENTER to view diagnostic information if desired.
Press ENTER key	Access diagnostic information.	<pre> STOP FREQ REF LOCAL 2.00 HZ </pre>	.
Press DISP key	Display mode showing control temperature.	<pre> STOP CONTROL TEMP LOCAL 25.0° C </pre>	Displays operating temperature in degrees C.
Press DISP key	Display mode showing bus voltage.	<pre> STOP BUS VOLTAGE LOCAL 321V </pre>	
Press DISP key	Display mode showing bus Current.	<pre> STOP BUS CURRENT LOCAL 0.00A </pre>	
Press DISP key	Display mode showing PWM Frequency.	<pre> STOP PWM FREQ LOCAL 2497 HZ </pre>	
Press DISP key	Display mode showing % overload current remaining.	<pre> STOP OVRLO LEFT LOCAL 100.00% </pre>	
Press DISP key	Display mode showing real time opto inputs & outputs states. (0=Open, 1=Closed)	<pre> DIGITAL I/O 000000000 1110 </pre>	Opto Inputs states (Left); Opto Outputs states (Right).
Press DISP key	Display mode showing actual drive running time since the Fault log was cleared.	<pre> TIME FROM PWR UP 0000000.01.43 </pre>	HR.MIN.SEC format.
Press DISP key	Display operating zone with rated hp and input voltage (for the operating zone) and control type.	<pre> 1 HP STD CT 230V INVERTER </pre>	
Press DISP key	Display mode showing continuous amps; PK amps rating; amps/volt scale of feedback, power base ID.	<pre> X.XA X.XAPK X.XXA/V ID.XXX </pre>	
Press DISP key	Display mode showing which Group1 or 2 expansion boards are installed.	<pre> I NOT INSTALLED II NOT INSTALLED </pre>	
Press DISP key	Display mode showing software version and revision installed in the control.	<pre> SOFTWARE VERSION XXX-X.XX </pre>	
Press DISP key	Displays exit choice. Press ENTER to exit.	<pre> PRESS ENTER FOR DIAGNOSTIC EXIT </pre>	Press ENTER to exit diagnostic information.

HOW TO ACCESS THE FAULT LOG

When a fault condition occurs, motor operation stops and a fault code is displayed on the Keypad display. The control keeps a log of the last 31 faults. If more than 31 faults have occurred, the oldest fault will be deleted from the fault log. To access the fault log, perform the following procedure:

Action	Description	Display	Comments
Apply Power	Display mode showing Local mode voltage, current & frequency status.	<pre>STP 0V REDIFL2 LOC 0.0 A 0.0 HZ</pre>	No faults present. Local keypad mode. If in remote/serial mode, press local for this display.
Press DISP key	Press DISP to scroll to the Fault Log entry point.	<pre>PRESS ENTER FOR FAULT LOG</pre>	Typical display.
Press ENTER key	Display first fault type and time fault occurred.	<pre>EXTERNAL TRIP 1: 0:00:30</pre>	
Press ▲ key	Scroll through fault messages.	<pre>PRESS ENTER FOR FAULT LOG EXIT</pre>	If no messages, the fault log exit choice is displayed.
Press RESET key	Return to display mode.	<pre>STOP FREQUENCY LOCAL 0.00 HZ</pre>	Display mode stop key LED is on.

How to Clear the Fault Log Use the following procedure to clear the fault log.

Action	Description	Display	Comments
Apply Power	Display mode showing Local mode voltage, current & frequency status.	<pre>STP 0V REDIFL2 LOC 0.0 A 0.0 HZ</pre>	Display mode.
Press DISP key	Press DISP to scroll to the Fault Log entry point.	<pre>PRESS ENTER FOR FAULT LOG</pre>	No faults in fault log.
Press ENTER key	Displays most recent message.	<pre>EXTERNAL TRIP 1: 00000:00:30</pre>	
Press SHIFT key		<pre>EXTERNAL TRIP 1: 00000:00:30</pre>	
Press RESET key		<pre>EXTERNAL TRIP 1: 00000:00:30</pre>	
Press SHIFT key		<pre>EXTERNAL TRIP 1: 00000:00:30</pre>	
Press ENTER key	Fault log is cleared.	<pre>FAULT LOG NO FAULTS</pre>	
Press ▲ or ▼ key	Scroll Fault Log Exit.	<pre>PRESS ENTER FOR FAULT LOG EXIT</pre>	
Press ENTER key	Return to display mode.	<pre>PRESS ENTER FOR DIAGNOSTIC INFO</pre>	

FAULT MESSAGES

FAULT MESSAGE	DESCRIPTION
Invalid Base ID	Failure to determine control horsepower and input voltage configuration from the Power Base ID value in software.
NV Memory Fail	Failure to read or write to non-volatile memory.
Param Checksum	Parameter Checksum error detected.
Low INIT Bus V	Low bus voltage detected on startup.
HW Desaturation	High output current condition detected (greater than 400% of rated output current). On B2 size controls, a desat error can indicate any of the following: low line impedance, brake transistor failure or internal output transistor overtemperature.
HW Surge Current	High output current condition detected (greater than 250% of rated output current).
HW Ground Fault	Ground Fault detected (output current leakage to ground).
HW Power Supply	Control Board power supply failure detected.
Hardware Protect	A general hardware fault was detected but cannot be isolated.
1 MIN Overload	Peak output current exceeded the 1 minute rating value.
3 SEC Overload	Peak output current exceeded the 3 second rating value.
Overcurrent	Continuous current limit exceeded.
BUS Overvoltage	High DC Bus voltage.
Bus Undervoltage	Low DC Bus voltage condition detected.
Heat Sink Temp	Control heatsink exceeded upper temperature limit. For size B2 controls, this fault may indicate the main heatsink or the gate drive circuit board is too hot.
External Trip	Connection between J4-16 and J4-17 is open.
New Base ID	Control board detected a change in the Power Base ID value in software.
REGEN RES Power	Excessive power dissipation required by Dynamic Brake Hardware.
Line REGEN	Fault in Line REGEN converter unit - Series 21H Line REGEN Inverter control.
EXB Selection	Expansion board not installed to support the selected Level 1 Input Block, Command Select parameter.
Torque Proving	Unbalanced current in the three phase motor leads.
Unknown FLT Code	Microprocessor detected a fault that is not identified in the fault code table.
μP RESET	A software watchdog timer has reset the processor because a process has timed out.
FLT Log MEM Fail	Corrupt data in fault log (may occur on older systems only).
Current SENS FLT	Failure to sense phase current.
Bus Current SENS	Failure to sense bus current.

TECHNICAL SPECIFICATIONS

DESCRIPTION	RF2	RF4
Part I	Rated Power & Markings	
Input Voltage	1 X 115V +/- 10% or 1 X 230V +/- 10%	
	Single Phase Input	
Output Voltage	3 X 220V	3 X 230V
Continuous Output Current (230V input)	6.05A	8.25A
Continuous Output Current (115V input)	6.05A	6.50A
Part II	Fundamental Parameters	
Control System	PWM	
Output Voltage	Clamp @ 220V	Clamp @ 230V
Carrier Freq.	Selectable: 1-5 KHz	
Freq. Resolution	0.1Hz*	
Input Freq. Range	48 – 62 Hz	
Maximum Output Frequency(230V input)	400 Hz	100 Hz
Maximum Output Frequency(115V input)	400 Hz	80 Hz
Base Frequency	400 Hz	100 Hz
Torque Boost	0 – 15% Nominal Voltage	
V/F Pattern	Selectable Linear/Square Law	
Accel Time	0.5 – 3600 Seconds	
Decel Time	0.5 – 3600 seconds	
Accel/Decel Pattern	Linear	
Part III	Protective Functions	
Ground Fault	Ground Fault detection for Equipment Protection	
Overcurrent	Output Short Circuit Locked Rotor	
Over Voltage	400VDC	
Under Voltage	200VDC	
Motor Overload	I ² x T Characteristic	
Line Start Lock Out	VFD will not start upon input power application	
Line Transient Rating	860 VAV, 810J MOV Between any power input terminal & Ground 360 VAC, 380 J MOV Between any two power input terminals	
Part IV	Ambient Operating Conditions	
Operating Temp.	-10 to 40 degree C	
Storage Temp.	-30 to 65 degree C	
Vibration	0.5G, Max / 57-150 Hz	
Elevation	3300 ft. without derating	
Max source fault current	5 Kamps	
Enclosure rating	UL Type 4, No Direct Sunlight	

WARRANTY SERVICE

The Redi-Flo VFD is covered by the original equipment manufacturers warranty for a period of 24 months. To obtain warranty services, contact the distributor or dealer from which it was purchased to obtain instructions. **Under no circumstances should defective product be returned to the distributor, dealer, or GRUNDFOS without a return materials authorization (RMA).**

SERVICE PARTS

Only four repair parts are available, the carrying case, the keypad, power cord and Harting motor connection. Contact the dealer from which the unit was purchased for these parts.

L-RF-IO-009	Rev. 06/02
Printed in the U.S.A.	

North American Regional Headquarters
Grundfos Pumps Corporation
17100 W. 118th Terrace
Olathe, KS 66061
Telephone (913) 227-3400
Fax: (913) 227-3500

www.grundfos.com

Grundfos Canada, Inc.
2941 Brighton Road
Oakville, Ontario L6H 6C9, Canada
Telephone: (905) 829-9533
Fax: (905) 829-9512

Bombas Grundfos de Mexico, S.A. de C.V.
Boulevard TLC #15
Parque Stiva Aeropuerto
Apodaca, N.L. Mexico
C.P. 66600
Telephone: 52-81-8144-4000
Fax: 52-81-8144-4010